



## AJAX

### Remote control

### SPACECONTROL-W

#### FUNCTIONS (ALARM CONTROL)

|                  |            |
|------------------|------------|
| Armed            | <b>Sí</b>  |
| Disarmed         | <b>Sí</b>  |
| Alarma de pánico | <b>Sí</b>  |
| Indicator        | <b>Led</b> |
| Partial armed    | <b>Sí</b>  |

#### POWER CONSUMPTION

|                  |                        |
|------------------|------------------------|
| Built in battery | <b>Yes</b>             |
| Battery model    | <b>1 x CR2032 / 3V</b> |
| Battery duration | <b>Up to 5 años</b>    |

#### VIA RADIO

|                       |                                         |
|-----------------------|-----------------------------------------|
| Frequency             | <b>868.0 MHz ~ 868.6 MHz</b>            |
| Transmission distance | <b>Up to 1300 m (without obstacles)</b> |
| Maximum power RF      | <b>Hasta 20 mW</b>                      |

#### MATERIAL AND DIMENSIONS

|                       |                        |
|-----------------------|------------------------|
| Dimensions            | <b>65 x 37 x 10 mm</b> |
| Net weight            | <b>15 g</b>            |
| Color                 | <b>White</b>           |
| <b>AMBIENT</b>        |                        |
| Operating temperature | <b>-20 °C ~ 50 °C</b>  |
| Maximum humidity      | <b>90%</b>             |

